



THIS SPACE FOR LAB ONLY

LT

LT

RADON LONG TERM TEST INFORMATION SHEET

TEST INSTRUCTIONS ON BACK

Please read **ALL** instructions before beginning test. Instructional Video online at DrHomeAir.com/LTVideo
 Please print legibly in dark ink. Made a mistake? Print another copy at DrHomeAir.com/Forms
 Instead of completing this sheet, you may register your test information online at DrHomeAir.com/Register

Last Name:

First Name:

Mailing Address:

City:

State: ZIP: Phone #: - -

How would you like to receive your report
 Please mark ONE box with an "X"

Email Fax Mail

Test results also available
 Online 24/7 at DrHomeAir.com/Results

Email:

Fax: - -

*** THE TEST SHOULD BE RUN BETWEEN 90-365 DAYS ***

Record the Test Kit Serial # for your own records.
 It is required when contacting the lab for any reason.
 Tip: Take a picture of this completed form!

Test Kit Serial #: A T -

Test Start Date: / /
Month Day Year

Test Stop Date: / /

Test Floor: Basement 1st Floor 2nd Floor 3rd Floor + Other

Structure Type: Slab (No Basement) Crawl Space Basement Multi-Story (No Basement)

Testing Reason: Real-Estate Transaction Post Mitigation Personal Knowledge

Room Location:
(Example: Living Room)

*** COMPLETE ONLY IF TEST ADDRESS IS DIFFERENT FROM THE ADDRESS ABOVE ***

Test Address:

City:

State: ZIP:

LT



Step 1 - BEFORE TESTING:

- **Read through all instructions on this sheet to fully understand the test and to avoid mistakes.**
Your test kit should include a long term radon sampler (black plastic disk), this information sheet, and a return mailer.
- Use your home as you normally would during the testing period. Dehumidifiers, heating, and cooling systems should be run normally.
- Questions? Refer to our Frequently Asked Questions online at DrHomeAir.com/FAQ, or email us at radon@alphaenergylabs.com.
- Instead of filling out this sheet, you may register your test online at DrHomeAir.com/Register. This will speed up your test results.
- Record your name, address, Test Kit Serial #, and test location on the front of this sheet. Make sure to record the Test Kit Serial # for your own records as well. The Test Kit Serial # is located on the flat side of the radon sampler.
- Record your phone number on the front of this sheet. We will send you a text message when your report is complete. Leave your phone number blank if you do not want to receive this text message. We will not use your phone number for marketing purposes.
- Choose how you would like to receive your results. If you choose email, we will email your report from **radon@alphaenergylabs.com**.

Step 2 - START THE TEST:

- **Remove the radon sampler from the plastic bag. This starts your radon test.**
- Record your start date on this information sheet.
- Place the radon sampler using these guidelines:
DO:
 - Place the radon sampler on the lowest level of your home suitable for occupancy, whether it is finished or unfinished.
 - Place the radon sampler on a flat surface with the flat side facing down.
 - Place the radon sampler 2-7 feet above the floor.
 - Place the radon sampler at least 3 feet from exterior doors and windows.
 - Place the radon sampler at least 6 inches from any wall or large object taller than 6 inches.**DO NOT:**
 - Do not place the radon sampler near heating or air conditioning vents, or a place where it will be exposed to constantly moving air.
 - Do not place the radon sampler where it will get wet.
 - Do not place the radon sampler in areas of high humidity (i.e. bathroom, crawlspace, or sump).
 - Do not place the radon sampler in closets, crawlspaces, or confined areas.
 - Do not place the radon sampler in direct sunlight or near heat sources.

Step 3 - PLAN TO STOP THE TEST:

- **Make sure to stop your test within the correct time period. Tests exposed for less than 90 days or more than 365 days are invalid and cannot be analyzed.**
- Make a note of the following for your own records:
 - Test Kit Serial # (Tip: take a picture with your cell phone!)
 - Date you will ship the package, tracking number, and shipping method (i.e. FedEx Ground 1/30/2018)
- On the outside of the mailer, print the Test Kit Serial # in the appropriate box.
- **No analysis fees are required.**

Step 4 - STOP TESTING AND MAIL YOUR PACKAGE:

- Record the stop date on this information sheet and complete any missing info. Test dates are required for test result.
- **Place this information sheet and radon sampler inside the mailer and seal it. This stops your radon test.**
- If you have more than one test, you can ship them all in one box or package. Each test must be sealed individually.
- **Mail the package to Alpha Energy Labs at 2501 Mayes Road Suite #100, Carrollton, TX 75006.**
- Your report will be completed and sent to you in approximately 3 weeks after receipt.
- You can track test status & download results online at DrHomeAir.com/Results. Please allow 1-2 business days after receipt for lab tracking.